NEW

SKI BOARD RELEASE DR 450

Jettison


By...

It's Faster!
It's Easier!
It Detects Shakers!
It's Better!

BIG JON



"We put our pride on the line"



Selling Features

Unique Design

- Eliminates need for extra release pins.
- Telegraphs any "action" to rod tip immediately.
- Allows release pin to be set for fishing conditions. i.e. light for small fish, tight for heavier fish!

Molded Plastic

- Resists corrosion.
- Prevents nicked lines!!


Simple Operation

- Release is not attached to fishing line. Thus, it is not a problem in setting out line or reeling in fish.


Here's how it works:

Step 1. Let out desired amount of line from fishing rod.


Step 2. Attach DR 450 to Skirigger line.



Step 3. Slide fishing line into slot in the end of the release pin.



Step 4. Push pin into holes in release as shown.



Step 5. When fish strikes bait (lure) the pin will pull out, releasing the fishing line from Skirigger.

Distributed by:

PAT. U.S. 4.177,599 CANADIAN 1,063,803